

Schlage eGO **Quick Start Guide**

The Schlage eGO lock is a Bluetooth capable smart lock that can be unlocked with a key, card or fob. In order to set up your lock, you will need the following:

- An Android or iPhone smart phone
- A card or fob if you wish to add unlocking credentials

How to set up your Schlage eGO Smart Lock

1. Download Schlage Breeze and create an account
2. Follow the instructions in Schlage Breeze to pair your lock to your mobile, a card/tag will be needed to wake the lock
3. Within Schlage Breeze choose "Grant Access" then "Add Credential" and follow the instructions to grant your card or fob access to your Schlage eGO



Schlage Breeze app
Google Play



Schlage Breeze app
Apple

If you are unable to pair your lock to Schlage Breeze, please contact API Access & Security at api.service@allegion.com

Unlocking your Schlage eGO Smart Lock

1. Present the card/tag to the external card reader
2. Rotate the lever downward and open the door



Note: the internal lever is always unlocked as a fire safety feature to ensure occupants can always exit at any time.

The privacy turn is designed to prevent other card holders from gaining access but can be overridden by the administrator through the Schlage Breeze app.

Battery replacement:

1. Lift top cover on the Internal side of lock
2. Remove top screw
3. Slide out battery holder
4. Replace 4 AAA batteries with alkaline batteries (batteries should last up to 12 months)



Schlage eGO can also be configured to be centrally managed by Schlage Breeze Hotel. The Schlage Breeze Hotel app is designed for centrally managed systems such as hotels, motels and other hospitality businesses. In instances where Schlage Breeze Hotel is used you should contact your building manager before attempting to reset the lock.

For more information on the Schlage eGO Smart Lock, Schlage Breeze apps or Schlage Breeze Hotel system, please contact our Customer Service team on 131 539 or at api.service@allegion.com